





## Spare parts kit

When seals are damaged due to wear of foreign material, it is necessary to replace them. **Original FASTER® spare parts kit** are available. Detailed instructions are included to achieve the correct replacement of damaged parts. No special tools are required to carry out replacement. Do not use sharpened tools to change the seals that could damage the new seals of the coupling itself.

A tool kit to replace the seals is available with code KIT UT2PO.

Series	Size		Spare part kit	
			Male coupling Standard seals	Female coupling Standard seals
3FFV38	3/8"	06	KIT 3FFV38 M	KIT 3FFV38 F
3FFV12	1/2"	08	KIT 3FFV12 M	KIT 3FFV12 F
3FFV34	3/4"	12	KIT 3FFV34 M	KIT 3FFV34 F
3FFV1	1"	16	KIT 3FFV1 M	KIT 3FFV1 FS
3FFV112	1 1/2"	24	KIT 3FFV112 M	KIT 3FFV112 FS

